

78

79

80

81

82

83

CONDENSOR
FAN MOTOR

C179

BK GN/BK

UNDERHOOD
LAMP SWITCH

C198

RW GN/W

COOLING FAN
MOTOR

C174

BL/Y

IGNITION
RELAY

C178

BK/R BK BK/R BK/W BK/R

BLOWER
FAN MOTOR
RELAY

C175

BL BL/R BK

ENGINE COOLANT
TEMPERATURE SENSOR

C150

Y/GN

COOLANT
TEMPERATURE
SWITCH

C176

BK/GN

ZONE F-84

REAR OF
MAIN FUSE
BLOCK

ZONE F-84

C108

Y/R WBK BK

C902

BK/R BK/R

A

B

C

D

E

F

GN/BK
BR/R
W/BK
BK/W
R/BK
W/BK
W/R
BL/O
BL/Y
R
GN/BK
BK/R
GN/W
GN/W
RW
Y/R
Y/GN
R/GN
BK/W
BK/Y
GN/BK
BK/GN
W/GN
BK
RW
BK
BK

GN/BK

C137

GN/BK



BK

BK

C148

GN/BK

C181

A/C CLUTCH
FIELD COIL

BK BL/R

C103

ZONE F-237
LEFT OF
RELAY BOX
AT LH
INTERIOR
KICK PANEL

R/GN BK/Y

C171

BACKUP LAMP
SWITCH

RW WBK W/R

C244



DIMMER RELAY

BK BL/O

C907

WASHER
PUMP
MOTOR

78

79

80

81

82

83