

111

112

113

114

115

116

A

R.H. DOOR KEY
CYLINDER LAMP
& SWITCHR.H. POWER
WINDOW SWITCHR.H. POWER
WINDOW
MOTORR.H. POWER
MIRROR MOTORR.H. DOOR
SPEAKERR.H. POWER
DOOR LOCK
MOTORR.H. POWER
DOOR LOCK
SWITCHR.H. DOOR
LATCH SWITCH
(PASSIVE RESTRAINT)

B

TO 10B942
ZONE 103-A
OR
ZONE 70-A
(ELECTRONIC
CLUSTER)

C

TO 14405
ZONE 102-F




D

TO 14405
ZONE 101-F

E

TO 10B942
ZONE 103-F
OR
ZONE 71-F
(ELECTRONIC
CLUSTER)

F

2.2L : GL
2.2L TURBO : GT
3.0L : LX

111

112

113

114

115

116