

83

84

85

86

87

88

SPEED CONTROL
MODULE (LX ONLY)CLUTCH SW.
(LX MTX ONLY)CLUTCH SW.
(GL, GT
& MTX ONLY)SPEED CONTROL MAIN
SW. (GL, GT ONLY)SPEED CONTROL
MODULE (GL, GT)SPEED CONTROL
ACTUATOR (GL)SPEED CONTROL
ACTUATOR (GT)STOP SW.
(GL, GT)

SOLID STATE

SOLID STATE

